



LOADING LEGUAN TRAILERS

- 1) Before loading or unloading the trailer, ensure it is parked on level firm ground.
- 2) Either make sure the trailer is securely fastened to the towing vehicle with the handbrake on and vehicle in gear, or;
- 3) Lower both rear stabilizer legs and engage the handbrake on the trailer.
- 4) If there is any doubt that the trailer could still move, place wheel chocks at tyres.
- 5) Ensure the stabilizer legs are fully retracted before driving machine.
- 6) When loading the Leguan, drive forwards onto the trailer, (drive controls are at the front of the scissor lift, and at the rear of the boom lift.)
- 7) Drive forwards just far enough to hook on the two rear tie-down chains, and then drive the machine forwards enough to put tension on these chains.
- 8) Hook on the two front chains and use the two dogs to pull the machine down nice and tight.
- 8) Check both rear chains to ensure they are both tight. If not, re-tension the front dogs.
- 9) Use a piece of tie-wire to secure the handles of the dogs to prevent them from opening in transit.
- 10) After driving for a few kilometres, pull over and double check the trailer and the tension of the chains. Re-tension if required.
- 11) Use caution when using the dogs, as they can spring open suddenly with great force.